

APPLICATION



1. Lay Silent-e TRIM strip



2. Unroll sheets



3. Lay the next roll



4. Stabilize the membrane by taping the joints



5. Lay the anti-shrinkage net of the regulating slab



6. Cast the regulation slab



7. Finished slab



8. Lay the finished floor